




创意源于追求
Own Idea Of Lighting

T18 PC T18 FC USER MANUAL



T18 PC/ T18 FC
SS9294



MODEL: SS9294SC/SCHC



— Since 1985 —

广州市雅江光电设备有限公司

Guangzhou Yajiang Photoelectric Equipment Ltd.

电话/ Tel : 020 - 86947788

邮箱/E-mail : sales @yajiang .cn

传真/Fax : 020 - 86943773


网址/Website : www.yajiang.cn

1 PRODUCT

1.1 TECHNICAL SPECIFICATIONS

Type	SS9294SC/SC HC
LED colors	1600W Cool White LED
Angle	5-55°
Power	1800W
Control Protocol	DMX512, RDM, Artnet, sACN, W-DMX(optional)
Voltage Range	100-240V~
Frequency Range	50/60Hz
Protection	IP20
Operation Temperature	0℃~45℃
Dimensions	483x284x802mm
Weight	45.5kg

Dimensions



1.2 Safety Notes

IMPORTANT

- This product must be installed by a qualified professional.
- In order to maintain this condition and to ensure a safe operation, it is absolutely necessary for the user to follow the safety instructions and warning notes
- The manufacturer will not accept liability for any resulting damages caused by the non-observance of this manual or any unauthorized modification to the device.

CAUTION!

- Make sure that the available voltage is not higher than stated on the rear panel.
- Do not touch the power cables if your hands are wet.
- The earth wire must always be connected to the ground. Therefore it is essential to connect the yellow/green conductor to earth.
- Make sure that the power-cord is never crimped or damaged by sharp edges. Check the device and the power-cord from time to time. The electric connection, repairs and servicing must be carried out by a qualified employee.
- Always disconnect power input cable to completely remove power from unit when not in use or before cleaning or servicing the fixture.
- Do not switch the fixture on and off in short intervals as this would reduce the LED's life.
- Do not touch the device's housing bare hands during its operation (housing becomes hot)! The surface of the product's casing can reach up to 60° C (140° F) during operation. Avoid contact by persons and materials. Do not install the product in a location where there is a risk of accidental contact. Allow the product to cool for at least 10 minutes before handling.
- For replacement use LEDs and fuses of same type and rating only.
- Please protect the fixture and avoid destroy during transport and installation. If there is any damage to the coating, the shell may be corroded.
- When hanging LEDs and lanterns, it is necessary to verify that facilities and hooks can bear at least 10 times the weight of LEDs and lanterns.
- Fix the safety rope at the correct holes only. Only operate the fixture after having checked that the housing is firmly closed and all screws are tightly fastened.
- The maximum ambient temperature 45°C must never be exceeded. Do not operate the product if the ambient temperature (Ta) exceeds 45° C (115° F).
- During the initial start-up some smoke or smell may arise. This is a normal process and does not necessarily mean that the device is defective.

Electrical Warning

- The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person
- For replacement use LEDs and fuses of same type and rating only.
- The lens has to be replaced when it is obviously damaged, so that its function is impaired, e. g. due to cracks or deep scratches!

Keep the product well away from flammable materials

- Keep all combustible materials (e.g. fabric, wood, paper) at least 500 mm (20 in.) away from the product.
- Ensure that there is free and unobstructed airflow around the product. Provide a minimum

clearance of 150 mm (6 in.) around fans and air vents.

- Do not illuminate surfaces within 3 m (10 ft.) of the product.
- Do not install a fuse that has a higher rating than the one originally installed in the product. Do not bypass fuses.
- Do not stick filters, masks or other materials onto optical components.
- If the fixture seems to be abnormally hot, shows signs of melting or emits smoke, disconnect the fixture from power immediately and allow it to cool. Do not touch the fixture without heatproof safety gloves. Keep the fixture well away from combustible and flammable materials.

**NEVER LOOK DIRECTLY INTO THE LIGHT SOURCE!
RETINA INJURY RISK - MAY INDUCE BLINDNESS!**

Do not point the front of the fixture towards the sun or other strong light sources. The front lens focuses and concentrates light just like a magnifying glass. Strong light can cause internal damage to the fixture, melting components or starting an internal fire within seconds.

To avoid problems from strong light sources:


- Do not expose the front of a fixture to sunlight or any other strong light source. Avoid pointing other high-powered beam lights directly at the fixture.
- Do not focus a light beam from one lighting fixture directly towards another.
- For outdoor applications during daylight, make sure that the front face of any fixture is shielded or points away from the sun, even when not in use.
- Do not expose the product to heat (from other lighting fixtures for example).

2 INSTALLATION

2.1 MOUNTING

Truss installation

- ◆ Keep all combustible materials (e.g. fabric, wood, paper) at least 500 mm (20 in.) away from the product.
- ◆ For overhead use, always install a safety cable that can hold at least 10 times the weight of the fixture.
- ◆ For overhead installation, the fixture must be always secured with a safety wire that can bear at least 10 times the weight of the fixture;
- ◆ Secure the fixture with a safety cable through the rear safety eye and truss as shown..
- ◆ Ensure that the structure (truss) to which you are attaching the fixture is secure



2.2 Fuse replacement

- ◆ Remove the safety cap by a screwdriver.
- ◆ Fetch the old fuse from safety cap.
- ◆ Install a new fuse.
- ◆ Install the safety cap.





2.3 POWER CONNECTIONS

- ◆ This product has an auto-ranging power supply that can work with an input voltage range of 100–240V~,50/60Hz.


2.4 Data network requirements

- ◆ Connect the DMX512 controller to the units in series. A DMX 512 data link is required in order to control the fixture via DMX. The fixture has 3/5-pin XLR connectors for DMX data input and output.
- ◆ Each unit has N DMX channels so the DMX Addresses should increase by increments of 1, (Nx1)+1, (Nx2)+1, (Nx3)+1...
- ◆ Any DMX address in the range from 001 to 512 may be used.
- ◆ Connect the DMX-output of the first fixture in the DMX chain with the DMX-input of the next fixture. Always connect one output with the input of the next fixture until all fixtures are connected.
- ◆ Caution: At the last fixture, the DMX-cable has to be terminated with a terminator. Solder a 120 Ω resistor between Signal (–) and Signal (+) into a 3/5-pin XLR-plug and plug it in the DMX-output of the last fixture.



DMX-output
XLR mounting-sockets



DMX-input
XLR mounting-plugs




1-Ground
2-Shield(-)
3-Shield(+)
4-Not connected
5-Not connected



3 FUNCTIONS AND SETTINGS

3.1 DISPLAY OPERATION

- ◆ MENU: Used to access the menu or to return a previous menu option;
- ◆ ENTER: Used to select and store the current menu or confirm the current function value or option within a menu;
- ◆ UP: Navigates downwards through the menu list and increases the numeric value when in a function;
- ◆ DOWN: Navigates upwards through the menu list and decreases the numeric value when in a function;



3.2 Menu Map

ADDRESS	001 - 512（default 001）			DMX address setting
PERSON	BASIC			Use the menu to select desired channel mode
	STANDARD（default）			
	Extend			
RUNMODE	DMX512（default）			Select Signal Default: DMX512 CUSTOM1-2 Set up get into EDIT MENU edit
	ARTNET			
	ARTNET TO DMX			
	sACN			
	AUTO			
	CUSTOM1			
	CUSTOM2			
OPTION	USER MODE	USER A（default）		Set default option mode A
		USER B		Set default option mode B
		USER C		Set default option mode C
	PAN INVERT	OFF（default）		PAN moving direction selection
		ON		
	TILT INVERT	OFF（default）		TILT moving direction selection
		ON		
	BLACKOUT	OFF（default）		Select OFF blackout without delay
		ON		Select ON Blackout delay 3s
	PAN SPEED	STUDIO	0-255	Pan rotation speed adjustment
		STANDARD	0-255	
	TILT SPEED	STUDIO	0-255	Tilt rotation speed adjustment
		STANDARD	0-255	
	PERFORM	STUDIO		Fan mode low speed
		POWER		Fast rotation of fan，all power
		LIVE（default）		Automatic rotation of fan

EDIT	DIMMER	DIM4 (default)			Dimming curves DIM1 (fast) to DIM4 (slow);	
		DIM3				
		DIM2				
		DIM1				
		OFF				
	LED PWM	1200Hz (default)			Sets the PWM frequency	
		2400Hz				
		4000Hz				
		6000Hz				
		25000Hz				
	DMX ERROR	SAVE (default)			Hold after loss of DMX signal	
		BLACK			Blackout after loss of DMX signal	
	DISPLAY TIME	On			Display backlight always on	
		10s			Turns off display backlight after 10s/1mins/2min of inactivity	
		1min (default)				
		2min				
	DISPLAY LOCK	OFF			Locks display (passcode is <UP>, <DOWN>,<UP>, <DOWN>, <ENTER>)	
		ON (default)				
	LOAD PARA	YES			Upload data	
		NO			Not upload data	
	SETTING	RECOVERY	****			Restore default factory settings.
		CLEAN EDIT1	****			Clean customer self-editing scene 1
		CLEAN EDIT2	****			Clean customer self-editing scene 2
		WDMX HIDE	YES			Hide wireless mode WDMX reset and signal hide and the default is wired mode only
			NO			
	NETWORK	Net SWITCH	OFF			Net switch off IP mode
			ON			Net switch on IP mode
		UNIVERS	0-255			Packet group Settings
		IP MODE	DEFAUL IP			Default IP
			CUSTOM IP			Customer's IP
		CUSTOM IP	XX.XX.XX.XX			Customer's IP setting
	PT ENCODER	OFF			XY Encoder switch.	
		ON			OFF is close; ON is open.	
	WDMX RESET	NO			Clear the receiver's message	
		YES			Do not clear the receiver's message.	
	SIGNAL	ONLY XLRDMX			ONLY XLR is wire only	
		XLRDMX FIRST			XLR FIRST is wire first	
		ONLY WDMX			ONLY WDMX is wireless only	
		WDMX FIRST			WDMX FIRS is wireless first	
		WDMX TO XLRDMX			WDMX TO DMX is wireless to wired	
EDIT 1-2	STEP 1-30	PAN	0-255	Edit the custom programs1-30		
		TILT	0-255	Select play 【EDIT 1】 in		
		PT SPEED	0-255	RUNMOEDE CUSTOM 1; Select		
		CMY C	0-255	play 【EDIT 2】 in RUNMOEDE		

			CMY M	0-255	CUSTOM 2
			CMY Y	0-255	
			CTO	0-255	
			COLOR 1	0-255	
			COLOR 2	0-255	
			FROST 1	0-255	
			FROST 2	0-255	
			ZOOM	0-255	
			FOCUS	0-255	
			IRIS	0-255	
			FRAMING1.L	0-255	
			FRAMING1.R	0-255	
			FRAMING2.L	0-255	
			FRAMING2.R	0-255	
			FRAMING3.L	0-255	
			FRAMING3.R	0-255	
			FRAMING4.L	0-255	
			FRAMING4.R	0-255	
			FRAMING ROT	0-255	
			DIMMER	0-255	
			STROBE	0-255	
			TIME	0-255	
			USE	YES	Select YES to run the steps user need.
				NO	
MANUAL	Auto Test	OFF		Auto Test channel	
		ON			
	CHANNEL	PAN	0-255	Manual control channel	
		TILT	0-255		
		PT SPEED	0-255		
		CMY C	0-255		
		CMY M	0-255		
		CMY Y	0-255		
		CTO	0-255		
		COLOR1	0-255		
		COLOR 2	0-255		
		FROST 1	0-255		
		FROST 2	0-255		
		ZOOM	0-255		
		FOCUS	0-255		
		IRIS	0-255		
		FRAMING1.L	0-255		
		FRAMING1.R	0-255		
		FRAMING2.L	0-255		
		FRAMING2.R	0-255		
		FRAMING3.L	0-255		

		FRAMING3.R	0-255	
		FRAMING4.L	0-255	
		FRAMING4.R	0-255	
		FRAMING ROT	0-255	
		DIMMER	0-255	
		STROBE	0-255	
	DEBUG HIDE	NO		Factory testing mode. All stepper motors are not controlled by signal, It only works again after the reset.
		YES		
	RESET	ALL RESET		Select Yes/No to carry out all reset
		PT RESET		Select Yes/No to carry out P/T reset
		COLOR SYSTEM		COLOR reset
		FOCUS\ZOOM SYS		FOCUS\ZOOM reset
		FRAMING SYS		FRAMING reset
	INFO	FIXTURE HOURS		Hours of fixture use
		LED USE HOURS		LED use time
		TEMPERATURE		LED temperature
VERSION		Software versions		
NETWORK		Check network parameter		
RDM		UID	0x388Axxxxxxxx	Check fixture's ID
		LABEL		Check fixture's LABEL
SYSTEM ERROR		MEMORY IC		Memory IC
		ANGLESENSOR		Angle Sensor
		PAN SENSOR		Pan Sensor
		PAN ENCODER		Pan Encoder
		PAN DRIVEIC		Pan Drive IC
		TILT SENSOR		Tilt Sensor
		TILT ENCODER		Tilt Encoder
		TILT DRIVEIC		Tilt Drive IC
		TEMPERATURE		Temperature
		CMY_C RESET		CMY C Reset
		CMY_M RESET		CMY M Reset
		CMY_Y RESET		CMY Y Reset
		CTO		CTO Reset
		COLOR 1 RESET		COLOR 1 Reset
		COLOR 2 RESET		COLOR 2 Reset
		FROST 1 RESET		FROST 1 Reset
		FROST 2 RESET		FROST 2 Reset
		ZOOM RESET		ZOOM Reset
		FOCUS RESET		FOCUS Reset
		FRAMING		FRAMING Reset
SERVICE	****	PAN	±127	Pan position fine adjustment
		TILT	±127	Tilt position fine adjustment
		CMY-C	±127	CMY-C position fine adjustment
		CMY-M	±127	CMY-M position fine adjustment
		CMY-Y	±127	CMY-Y position fine adjustment

		CTO	±127	CTO position fine adjustment
		COLOR 1	±127	COLOR 1 position fine adjustment
		COLOR 2	±127	COLOR 2 position fine adjustment
		ZOOM	±127	ZOOM position fine adjustment
		FOCUS	±127	FOCUS position fine adjustment
		IRIS	±127	IRIS position fine adjustment
		FRAMING1.L	±127	Prism 1 position fine adjustment
		FRAMING1.R	±127	Prism 2 position fine adjustment
		FRAMING2.L	±127	Framing position fine adjustment
		FRAMING2.R	±127	Framing position fine adjustment
		FRAMING3.L	±127	Framing position fine adjustment
		FRAMING3.R	±127	Framing position fine adjustment
		FRAMING4.L	±127	Framing position fine adjustment
		FRAMING4.R	±127	Framing position fine adjustment
		FRAMING ROT	±127	Framing position fine adjustment

4 USING A DMX512 CONTROLLER

4.1 DMX CONTROL

BASIC (28CH)	STANDARD (33CH)	Extend (37CH)	Value	Function
CH.1	CH.1	CH.1	000-255	PAN 0-540°
-	CH.2	CH.2	000-255	PAN FINE
CH.2	CH.3	CH.3	000-255	TILT 0-270°
-	CH.4	CH.4	000-255	TILT FINE
CH.3	CH.5	CH.5	000-255	PT Speed
CH.4	CH.6	CH.6	000-255	CYAN
CH.5	CH.7	CH.7	000-255	MAGENTA
CH.6	CH.8	CH.8	000-255	YELLOW
CH.7	CH.9	CH.9	000-255	CTO
CH.8	CH.10	CH.10	COLOUR MACRO	
			000-019	No Function
			020-021	3000K
			022-023	3200K
			024-025	3500K
			026-027	4000K
			028-029	4500K
			030-031	5000K
			032-033	5400K
			034-035	5600K
			036-037	6000K
			038-039	6500K
			040-041	6800K
			042-043	L106
			044-045	L194
			046-047	L019
			048-049	R08
			050-051	L213
			052-053	R80
			054-055	L202
			056-057	L328
			058-059	R3314
			060-061	L101
			062-063	L768
			064-255	MACRO EFFECT R->G->B->R
CH.9	CH.11	CH.11	000-255	CMYK SPEED(SPEED 100%->1)
CH.10	CH.12	CH.12	COLOR WHEEL 1	
			000-007	WHITE
			008-015	COLOR 1
			016-023	COLOR 2
			024-031	COLOR 3

			032-039	COLOR 4
			040-047	COLOR 5
			048-055	COLOR 6
			056-063	COLOR 7
			064-191	COLOR WHEEL 0-360°
			192-222	COLOR WHEEL RAINBOW EFFECT(SPEED 100%→1)
			223-224	STOP
			225-255	COLOR WHEEL RAINBOW EFFECT(SPEED 1→100%)
-	-	CH.13	000-255	COLOR WHEEL FINE
CH.11	CH.13	CH.14	COLOR WHEEL 2	
			000-007	WHITE
			008-015	COLOR 1
			016-023	COLOR 2
			024-031	COLOR 3
			032-039	COLOR 4
			040-047	COLOR 5
			048-055	COLOR 6
			056-063	COLOR 7
			064-191	COLOR WHEEL 0-360°
			192-222	COLOR WHEEL RAINBOW EFFECT(SPEED 100%→1)
			223-224	STOP
			225-255	COLOR WHEEL RAINBOW EFFECT(SPEED 1→100%)
-	-	CH.15	000-255	COLOR WHEEL FINE
CH.12	CH.14	CH.16	FROST 1	
			0-255	FROST (0-100%)
CH.13	CH.15	CH.17	FROST 2	
			0-255	FROST (0-100%)
CH.14	CH.16	CH.18	IRIS	
			0-127	IRIS OPEN → CLOSE (FROM LARGE TO SMALL)
			128-130	IRIS CLOSE
			131-171	IRIS FADE IN FADE OUT
			172-211	IRIS FAST IN FADE OUT RANDOMLY
			212-251	IRIS FADE IN FAST OUT RANDOMLY
			252-255	IRIS CLOSE
			000-255	IRIS FINE
CH.15	CH.17	CH.20	0-255	ZOOM
-	CH.18	CH.21	0-255	ZOOM FINE
CH.16	CH.19	CH.22	0-255	FOCUS
-	CH.20	CH.23	0-255	FOCUS FINE
CH.17	CH.21	CH.24	0-255	FRAMING1.Left
CH.18	CH.22	CH.25	0-255	FRAMING1.Right
CH.19	CH.23	CH.26	0-255	FRAMING2.Left
CH.20	CH.24	CH.27	0-255	FRAMING2.Right

CH.21	CH.25	CH.28	0-255	FRAMING3.Left
CH.22	CH.26	CH.29	0-255	FRAMING3.Right
CH.23	CH.27	CH.30	0-255	FRAMING4.Left
CH.24	CH.28	CH.31	0-255	FRAMING4.Right
CH.25	CH.29	CH.32	ALL FRAMING ROTATION	
			0-255	FRAMING ROT
-	-	CH.33	0-255	FRAMING ROTATION FINE
CH.26	CH.30	CH.34	0-255	DIMMER
-	CH.31	CH.35	0-255	DIMMER FINE
CH.27	CH.32	CH.36	STROBE	
			0-9	NO FUNCTION
			10-99	STROBE (FROM SLOW TO FAST)
			100-109	NO FUNCTION
			110-179	LIGHTNING STROBE
			180-189	NO FUNCTION
			190-255	RANDOM SROBE
CH.28	CH.33	CH.37	CONTROL	
			000-010	NO FUNCTION
			011-020	PAN/TILT BLACK ACTIVATED
			021-030	PAN/TILT BLACK DEACTIVATED
			031-040	PAN INVERT
			041-050	TILT INVERT
			051-060	PAN/TILT INVERT OFF
			061-070	STUDIO
			071-080	POWER
			081-090	LIVE
			091-100	RESERVE
			101-110	DIM4
			111-120	DIM0
			121-150	RESERVE
			151-160	1200Hz
			161-170	2400Hz
			171-180	4000Hz
			181-190	6000Hz
			191-200	25000Hz
			201-210	ALL RESET
			211-220	XY RESET
			221-230	COLOR SYSTEM RESET
			231-240	FOCUS/ZOOM RESET
			241-255	FRAMING RESET(EXECUTE AFTER 3 SECONDS)