




创意源于追求
Own Idea Of Lighting

T8

USER MANUAL

 T8
SS9185



MODEL: SS9185SC/ SS9185SC HC



广州市雅江光电设备有限公司

Guangzhou Yajiang Photoelectric Equipment Ltd.

电话/ Tel : 020-86947788 邮箱/ E-mail : sales@yajiang.cn

传真/ Fax : 020-86943773 网址/ Website : www.yajiang.cn


Since 1985

1 PRODUCT

1.1 TECHNICAL SPECIFICATIONS

Type	SS9185SC/SS9185SC HC
LED colors	600W Cool White LED
Angle	5-50°
Power	880W
Control Protocol	DMX512, RDM, W-DMX(optional)
Voltage Range	100-240V~
Frequency Range	50/60Hz
Protection	IP20
Operation Temperature	0°C~45°C
Dimensions	483x282x754mm
Weight	35.7kg

Dimensions



1.2 Safety Notes

IMPORTANT

- This product must be installed by a qualified professional.
- In order to maintain this condition and to ensure a safe operation, it is absolutely necessary for the user to follow the safety instructions and warning notes
- The manufacturer will not accept liability for any resulting damages caused by the non-observance of this manual or any unauthorized modification to the device.

CAUTION!

- Make sure that the available voltage is not higher than stated on the rear panel.
- Do not touch the power cables if your hands are wet.
- The earth wire must always be connected to the ground. Therefore it is essential to connect the yellow/green conductor to earth.
- Make sure that the power-cord is never crimped or damaged by sharp edges. Check the device and the power-cord from time to time. The electric connection, repairs and servicing must be carried out by a qualified employee.
- Always disconnect power input cable to completely remove power from unit when not in use or before cleaning or servicing the fixture.
- Do not switch the fixture on and off in short intervals as this would reduce the LED's life.
- Do not touch the device's housing bare hands during its operation (housing becomes hot)! The surface of the product's casing can reach up to 60° C (140° F) during operation. Avoid contact by persons and materials. Do not install the product in a location where there is a risk of accidental contact. Allow the product to cool for at least 10 minutes before handling.
- For replacement use LEDs and fuses of same type and rating only.
- Please protect the fixture and avoid destroy during transport and installation. If there is any damage to the coating, the shell may be corroded.
- When hanging LEDs and lanterns, it is necessary to verify that facilities and hooks can bear at least 10 times the weight of LEDs and lanterns.
- Fix the safety rope at the correct holes only. Only operate the fixture after having checked that the housing is firmly closed and all screws are tightly fastened.
- The maximum ambient temperature 45°C must never be exceeded. Do not operate the product if the ambient temperature (Ta) exceeds 45° C (115° F).
- During the initial start-up some smoke or smell may arise. This is a normal process and does not necessarily mean that the device is defective.

Electrical Warning

- The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person
- For replacement use LEDs and fuses of same type and rating only.
- The lens has to be replaced when it is obviously damaged, so that its function is impaired, e.g. due to cracks or deep scratches!

Keep the product well away from flammable materials

- Keep all combustible materials (e.g. fabric, wood, paper) at least 500 mm (20 in.) away from the product.
- Ensure that there is free and unobstructed airflow around the product. Provide a minimum

clearance of 150 mm (6 in.) around fans and air vents.

- Do not illuminate surfaces within 3 m (10 ft.) of the product.
- Do not install a fuse that has a higher rating than the one originally installed in the product.
- Do not bypass fuses.
- Do not stick filters, masks or other materials onto optical components.
- If the fixture seems to be abnormally hot, shows signs of melting or emits smoke, disconnect the fixture from power immediately and allow it to cool. Do not touch the fixture without heatproof safety gloves. Keep the fixture well away from combustible and flammable materials.

**NEVER LOOK DIRECTLY INTO THE LIGHT SOURCE!
RETINA INJURY RISK - MAY INDUCE BLINDNESS!**

Do not point the front of the fixture towards the sun or other strong light sources. The front lens focuses and concentrates light just like a magnifying glass. Strong light can cause internal damage to the fixture, melting components or starting an internal fire within seconds.

To avoid problems from strong light sources:


- Do not expose the front of a fixture to sunlight or any other strong light source. Avoid pointing other high-powered beam lights directly at the fixture.
- Do not focus a light beam from one lighting fixture directly towards another.
- For outdoor applications during daylight, make sure that the front face of any fixture is shielded or points away from the sun, even when not in use.
- Do not expose the product to heat (from other lighting fixtures for example).

2 INSTALLATION

2.1 MOUNTING

Truss installation

- ◆ Keep all combustible materials (e.g. fabric, wood, paper) at least 500 mm (20 in.) away from the product.
- ◆ For overhead use, always install a safety cable that can hold at least 10 times the weight of the fixture.
- ◆ For overhead installation, the fixture must be always secured with a safety wire that can bear at least 10 times the weight of the fixture;
- ◆ Secure the fixture with a safety cable through the rear safety eye and truss as shown..
- ◆ Ensure that the structure (truss) to which you are attaching the fixture is secure



2.2 Fuse replacement

- ◆ Remove the safety cap by a screwdriver.
- ◆ Fetch the old fuse from safety cap.
- ◆ Install a new fuse.
- ◆ Install the safety cap.




2.3 POWER CONNECTIONS

- ◆ This product has an auto-ranging power supply that can work with an input voltage range of 100–240V~, 50/60Hz.


2.4 Data network requirements

- ◆ Connect the DMX512 controller to the units in series. A DMX 512 data link is required in order to control the fixture via DMX. The fixture has 3/5-pin XLR connectors for DMX data input and output.
- ◆ Each unit has N DMX channels so the DMX Addresses should increase by increments of 1, (Nx1)+1, (Nx2)+1, (Nx3)+1...
- ◆ Any DMX address in the range from 001 to 512 may be used.
- ◆ Connect the DMX-output of the first fixture in the DMX chain with the DMX-input of the next fixture. Always connect one output with the input of the next fixture until all fixtures are connected.
- ◆ Caution: At the last fixture, the DMX-cable has to be terminated with a terminator. Solder a $120\ \Omega$ resistor between Signal (-) and Signal (+) into a 3/5-pin XLR-plug and plug it in the DMX-output of the last fixture.

DMX-output
XLR mounting-sockets




DMX-input
XLR mounting-plugs



3 FUNCTIONS AND SETTINGS

3.1 DISPLAY OPERATION

- ◆ MENU: Used to access the menu or to return a previous menu option;
- ◆ ENTER: Used to select and store the current menu or confirm the current function value or option within a menu;
- ◆ UP: Navigates downwards through the menu list and increases the numeric value when in a function;
- ◆ DOWN: Navigates upwards through the menu list and decreases the numeric value when in a function;



3.2 Menu Map

ADDRESS	001 – 512(Default 001)		DMX address setting	
PERSON	BASIC		Use the menu to select desired channel mode	
	STANDARD(Default)			
	Extend			
RUNMODE	DMX512 (Default)		Select Signal	
	AUTO		Default: DMX512	
	CUSTOM1		CUSTOM1-2 Set up get into EDIT	
	CUSTOM2		MENU edit	
OPTION	PAN INVERT	OFF (Default)	PAN moving direction selection	
		ON		
	TILT INVERT	OFF (Default)	TILT moving direction selection	
		ON		
	PERFORM	STUDIO	Fan mode low speed	
		POWER	Fast rotation of fan, all power	
		LIVE (Default)	Automatic rotation of fan	
	BLACKOUT	OFF (Default)	Select OFF blackout without delay	
		ON	Select ON Blackout delay 3s	
	DIMMER	DIM4 (Default)	Dimming curves DIM1 (fast) to DIM4 (slow):	
		DIM3		
		DIM2		
		DIM1		
		OFF		
	LED PWM	1200Hz (Default)	Sets the PWM frequency	
		2400Hz		
		4000Hz		

		6000Hz		
		25000Hz		
DMX ERROR	SAVE (Default)	Hold after loss of DMX signal		
	BLACK	Blackout after loss of DMX signal		
DISPLAY TIME	On	Display backlight always on		
	30s (Default)	Turns off display backlight after 30s/1min/2min of inactivity		
	1min			
	2min			
DISPLAY LOCK	OFF			
	ON (Default)	Locks display (passcode is <UP>, <DOWN>,<UP>,<DOWN>, <ENTER>)		
LOAD PARA	NO	Not upload data		
	YES	Upload data		
SETTING	RECOVERY	****	Restore default factory settings.	
	CLEAN EDIT1	****	Clean customer self-editing scene 1	
	CLEAN EDIT2	****	Clean customer self-editing scene 2	
	WDMX HIDE	YES	Hide wireless mode WDMX reset and signal hide and the default is wired mode only	
		NO		
PT ENCODER	OFF		XY Encoder switch. OFF is close; ON is open.	
	ON			
WDMX RESET	NO		Do not clear the receiver's message	
	YES		Clear the receiver's message	
SIGNAL	ONLY XLRDMX		ONLY XLR is wire only	
	XLRDMX FIRST		XLR FIRST is wire first	
	ONLY WDMX		ONLY WDMX is wireless only	
	WDMX FIRST		WDMX FIRS is wireless first	
	WDMX TO XLRDMX		WDMX TO DMX is wireless to wired	
EDIT	EDIT 1-2	PAN	0-255	Edit the custom programs1-30 Select play 【EDIT 1】 in RUNMOEDE CUSTOM 1; Select play 【EDIT 2】 in RUNMOEDE CUSTOM 2
		TILT	0-255	
		PT SPEED	0-255	
		CMY C	0-255	
		CMY M	0-255	
		CMY Y	0-255	
		CTO	0-255	
		COLOR	0-255	
		FIXED GOBO	0-255	
		ROTA.GOBO	0-255	
		GOBO.ROTA	0-255	
		ANIMATION.D	0-255	
		ANIMATION.R	0-255	
		PRISM	0-255	
		FROST	0-255	
		ZOOM	0-255	
		FOCUS	0-255	

			IRIS	0-255	
			FRAMING1.L	0-255	
			FRAMING1.R	0-255	
			FRAMING2.L	0-255	
			FRAMING2.R	0-255	
			FRAMING3.L	0-255	
			FRAMING3.R	0-255	
			FRAMING4.L	0-255	
			FRAMING4.R	0-255	
			FRAMING ROT	0-255	
			DIMMER	0-255	
			STROBE	0-255	
			TIME	0-255	
			USE	YES/NO	Select YES to run the steps user need.
MANUAL	Auto Test	OFF			
		ON			
CHANNEL		PAN	0-255	Manual control channel	
		TILT	0-255		
		PT SPEED	0-255		
		CMY C	0-255		
		CMY M	0-255		
		CMY Y	0-255		
		CTO	0-255		
		COLOR	0-255		
		FIXED GOBO	0-255		
		ROTA.GOBO	0-255		
		GOBO.ROTA	0-255		
		ANIMATION. D	0-255		
		ANIMATION. R	0-255		
		PRISM	0-255		
		FROST	0-255		
		IRIS	0-255		
		ZOOM	0-255		
		FOCUS	0-255		
		FRAMING1.L	0-255		
		FRAMING1.R	0-255		
		FRAMING2.L	0-255		
		FRAMING2.R	0-255		
		FRAMING3.L	0-255		
		FRAMING3.R	0-255		
		FRAMING4.L	0-255		
		FRAMING4.R	0-255		

		FRAMING ROT	0-255	
		DIMMER	0-255	
		STROBE	0-25	
INFO	DEBUG HIDE	NO		Factory testing mode. All stepper motors are not controlled by signal, It only works again after the reset.
		YES		
INFO	RESET	ALL RESET		Select Yes/No to carry out all reset
		PT RESET		Select Yes/No to carry out P/T reset
		COLOR SYSTEM		COLOR/CMYK reset
		OTHER		Zoom/ Focus/ Prism reset
	FIXTURE HOURS			
	LED USE HOURS			
	TEMPERATURE			
	VERSION			
	RDM	UID	0x388Axxxxxxxx	Check fixture's ID
		LABEL		Check fixture's LABEL
	SYSTEM ERROR	MEMORY IC		Memory IC
		ANGLESENSOR		Angle Sensor
		PAN SENSOR		Pan Sensor
		PAN ENCODER		Pan Encoder
		PAN DRIVEIC		Pan Drive IC
		TILT SENSOR		Tilt Sensor
		TILT ENCODER		Tilt Encoder
		TILT DRIVEIC		Tilt Drive IC
		TEMPERATURE		Temperature
		CMY_C RESET		CMY C Reset
		CMY_M RESET		CMY M Reset
		CMY_Y RESET		CMY Y Reset
		CTO		CTO Reset
		COLOR RESET		Color Reset
		FGOBO RESET		Fixed Gobo Reset
		GOBO RESET		Gobo Reset
		RGOBO RESET		Rotate Gobo Reset
		ANIMATION RESET		Animation Reset
SERVICE	*****	ZOOM RESET		Zoom Reset
		FOCUS RESET		Focus Reset
		PRISM RESET		Prism Reset
		FROST RESET		Frost Reset
		FRAMING		Framing Reset
		PAN	±127	Pan position fine adjustment
		TILT	±127	Tilt position fine adjustment
		COLOR	±127	Color position fine adjustment
		CMY-C	±127	CMY-C position fine adjustment
		CMY-M	±127	CMY-M position fine adjustment
		CMY-Y	±127	CMY-Y position fine adjustment

	CTO	± 127	CTO position fine adjustment
	FIXED GOBO	± 127	Fixed Gobo position fine adjustment
	ROTA.GOBO	± 127	Rotate Gobo position fine adjustment
	GOBO.ROTA	± 127	Self-rotation position fine adjustment
	ANIMATION	± 127	Animation position fine adjustment
	FOCUS	± 127	Zoom position fine adjustment
	ZOOM	± 127	Focus position fine adjustment
	IRIS	± 127	Iris position fine adjustment
	PRISM	± 127	Prism position fine adjustment
	FROST	± 127	Frost position fine adjustment
	FRAMING1.L	± 127	Framing position fine adjustment
	FRAMING1.R	± 127	Framing position fine adjustment
	FRAMING2.L	± 127	Framing position fine adjustment
	FRAMING2.R	± 127	Framing position fine adjustment
	FRAMING3.L	± 127	Framing position fine adjustment
	FRAMING3.R	± 127	Framing position fine adjustment
	FRAMING4.L	± 127	Framing position fine adjustment
	FRAMING ROT	± 127	Framing position fine adjustment

4 USING A DMX512 CONTROLLER

4.1 DMX CONTROL

BASIC (34CH)	STANDARD (40CH)	Extend (43CH)	Value	Function
CH.1	CH.1	CH.1	000-255	PAN 0-540°
-	CH.2	CH.2	000-255	PAN FINE
CH.2	CH.3	CH.3	000-255	TILT 0-270°
-	CH.4	CH.4	000-255	TILT FINE
CH.3	CH.5	CH.5	000-255	PT Speed
CH.4	CH.6	CH.6	000-255	CYAN
CH.5	CH.7	CH.7	000-255	MAGENTA
CH.6	CH.8	CH.8	000-255	YELLOW
CH.7	CH.9	CH.9	000-255	CTO 6800K-2700K
CH.8	CH.10	CH.10	COLOUR MACRO	
			000-019	No Function
			020-021	3000K
			022-023	3200K
			024-025	3500K
			026-027	4000K
			028-029	4500K
			030-031	5000K
			032-033	5400K
			034-035	5600K
			036-037	6000K
			038-039	6500K
			040-041	6800K
			042-043	L106
			044-045	L194
			046-047	L019
			048-049	R08
			050-051	L213
			052-053	R80
			054-055	L202
			056-057	L328
			058-059	R3314
			060-061	L101
			062-063	L768
			064-255	MACRO EFFECT R->G->B->R
CH.9	CH.11	CH.11	000-255	CMYK SPEED(SPEED 100%=>1)
CH.10	CH.12	CH.12	COLOR WHEEL 6+1	
			000-007	WHITE
			008-015	COLOR 1
			016-023	COLOR 2
			024-031	COLOR 3

			032-039 COLOR 4
			040-047 COLOR 5
			048-055 COLOR 6
			056-191 COLOR WHEEL1 0-360°
			192-222 COLOR WHEEL POSITIVE RAINBOW EFFECT(SPEED 100%=>1)
			223-224 STOP
			225-255 COLOR WHEEL REVERSE RAINBOW EFFECT(SPEED 1=>100%)
-	-	CH.13	000-255 COLOR WHEEL FINE
CH.11	CH.13	CH.14	ROTATING GOBO 7+1
			000-010 ROTATING WHITE
			011-018 ROTATING GOBO 1
			019-026 ROTATING GOBO 2
			027-034 ROTATING GOBO 3
			035-042 ROTATING GOBO 4
			043-050 ROTATING GOBO 5
			051-058 ROTATING GOBO 6
			059-066 ROTATING GOBO 7
			067-074 ROTATING GOBO 1 SHAKE (SPEED 1 —> 100%)
			075-082 ROTATING GOBO 2 SHAKE (SPEED 1 —> 100%)
			083-090 ROTATING GOBO 3 SHAKE (SPEED 1 —> 100%)
			091-098 ROTATING GOBO 4 SHAKE (SPEED 1 —> 100%)
			099-106 ROTATING GOBO 5 SHAKE (SPEED 1 —> 100%)
			107-114 ROTATING GOBO 6 SHAKE (SPEED 1 —> 100%)
			115-122 ROTATING GOBO 7 SHAKE (SPEED 1 —> 100%)
			123-127 WHITE
			128-190 STATIC GOBO POSITIVE WATER EFFECT (SPEED 100 —> 1%)
			191-192 STOP WATER EFFECT
			193-255 STATIC GOBO REVERSE WATER EFFECT (SPEED 1 —> 100%)
CH.12	CH.14	CH.15	GOBO ROTATING
			0-120 ROTATING GOBO ANGLE ADJUSTMENT (0 —> 360°)
			121-125 STOP
			126-165 ROTATING GOBO SHAKE (SPEED 1 —> 100%)
			166-170 STOP
			171-210 ROTATING GOBO POSITIVE ROTATION (SPEED 100% —> 1)
			211-215 STOP
-	CH.15	CH.16	216-255 ROTATING GOBO REVERSE ROTATION (SPEED 1 —> 100%)
			000-255 GOBO ROTATING FINE
CH.13	CH.16	CH.17	FIXED GOBO WHEEL8+1
			0-10 WHITE
			11-17 FIXED GOBO 1
			18-24 FIXED GOBO 2
			25-31 FIXED GOBO 3
			32-38 FIXED GOBO 4

			39-45	FIXED GOBO 5
			46-52	FIXED GOBO 6
			53-59	FIXED GOBO 7
			60-66	FIXED GOBO 8
			67-73	FIXED GOBO 9
			74-80	FIXED GOBO 10
			81-87	FIXED GOBO 1 SHAKE (SPEED 1 → 100%)
			88-94	FIXED GOBO 2 SHAKE (SPEED 1 → 100%)
			95-101	FIXED GOBO 3 SHAKE (SPEED 1 → 100%)
			102-108	FIXED GOBO 4 SHAKE (SPEED 1 → 100%)
			109-115	FIXED GOBO 5 SHAKE (SPEED 1 → 100%)
			116-122	FIXED GOBO 6 SHAKE (SPEED 1 → 100%)
			123-129	FIXED GOBO 7 SHAKE (SPEED 1 → 100%)
			130-136	FIXED GOBO 8 SHAKE (SPEED 1 → 100%)
			137-143	FIXED GOBO 9 SHAKE (SPEED 1 → 100%)
			144-150	FIXED GOBO 10 SHAKE (SPEED 1 → 100%)
			151-200	STATIC GOBO POSITIVE WATER EFFECT (SPEED 100 → 1%)
			201-205	STOP WATER EFFECT
			206-255	STATIC GOBO REVERSE WATER EFFECT (SPEED 1 → 100%)
CH.14	CH.17	CH.18	0-255	Insert effect wheel
			ANIMATION DISC ROTATION	
CH.15	CH.18	CH.19	0-10	Rotation STOP
			11-127	Animation Insertion CW Rotate Slow to Fast
			128-138	Rotation STOP
			139-255	Animation Insertion CCW Rotate Fast to Slow
			PRISM	
CH.16	CH.19	CH.20	0-10	WHITE
			11-145	PRISM INSERT AND ADJUST THE ANGLE (0 → 360°)
			146-150	STOP
			151-200	PRISM INSERT AND POSITIVE ROTATION (SPEED 100% → 1)
			201-205	STOP
			206-255	PRISM INSERT AND REVERSE ROTATION (SPEED 1 → 100%)
			FROST	
CH.17	CH.20	CH.21	0-255	FROST (0-100%)
			IRIS	
CH.18	CH.21	CH.22	0-127	IRIS OPEN → CLOSE (FROM LARGE TO SMALL)
			128-130	IRIS CLOSE
			131-171	IRIS FADE IN FADE OUT
			172-211	IRIS FAST IN FADE OUT RANDOMLY
			212-251	IRIS FADE IN FAST OUT RANDOMLY
			252-255	IRIS CLOSE
-	-	CH.23	000-255	IRIS FINE

CH.19	CH.22	CH.24	0-255	ZOOM
-	CH.23	CH.25	0-255	ZOOM FINE
CH.20	CH.24	CH.26	0-255	FOCUS
-	CH.25	CH.27	0-255	FOCUS FINE
CH.21	CH.26	CH.28	AUTO FOCUS	
			0-12	NO FUNCTION
			13-39	5 METER
			40-66	7 METER
			67-93	9 METER
			94-120	11 METER
			121-147	13 METER
			148-174	15 METER
			175-201	17 METER
			202-228	19 METER
			229-255	21 METER
CH.22	CH.27	CH.29	0-255	AUTO FOCUS FINE
CH.23	CH.28	CH.30	0-255	FRAMING1.Left
CH.24	CH.29	CH.31	0-255	FRAMING1.Right
CH.25	CH.30	CH.32	0-255	FRAMING2.Left
CH.26	CH.31	CH.33	0-255	FRAMING2.Right
CH.27	CH.32	CH.34	0-255	FRAMING3.Left
CH.28	CH.33	CH.35	0-255	FRAMING3.Right
CH.29	CH.34	CH.36	0-255	FRAMING4.Left
CH.30	CH.35	CH.37	0-255	FRAMING4.Right
CH.31	CH.36	CH.38	ALL FRAMING ROTATION	
			0-255	FRAMING ROT
-	-	CH.39	0-255	FRAMING ROTATION FINE
CH.32	CH.37	CH.40	0-255	DIMMER
-	CH.38	CH.41	0-255	DIMMER FINE
CH.33	CH.39	CH.42	STROBE	
			0-9	NO FUNCTION
			10-99	STROBE (FROM SLOW TO FAST)
			100-109	NO FUNCTION
			110-179	LIGHTNING STROBE
			180-189	NO FUNCTION
			190-255	RANDOM STROBE
CH.34	CH.40	CH.43	CONTROL	
			000-010	NO FUNCTION
			011-020	PAN/TILT BLACK ACTIVATED
			021-030	PAN/TILT BLACK DEACTIVATED
			031-040	PAN INVERT
			041-050	TIILT INVERT
			051-060	PAN/TILT INVERT OFF
			061-070	STUDIO
			071-080	POWER
			081-090	LIVE

091-100	LIVE
101-110	DIM4
111-120	DIM3
121-130	DIM2
131-140	DIM1
141-150	DIM0
151-160	1200Hz
161-170	2400Hz
171-180	4000Hz
181-190	6000Hz
191-200	25000Hz
201-210	ALL RESET
211-220	XY RESET
221-230	COLOR SYSTEM RESET
231-240	FOCUS\ZOOM RESET
241-255	FRAMING RESET(EXECUTE AFTER 3 SECONDS)